

Dante AVIO™



Network all your analog audio gear easily and cost-effectively with Dante AVIO

Dante AVIO Analog Adapters let you use your favorite analog audio gear with any Dante-connected system, delivering the interoperability, performance and scalability that only networking can bring. Cost effective, compact and built for the road, Dante AVIO adapters bring the modern network connectivity that every audio pro needs in their toolbox.

Dante AVIO analog adapters are available as input or output versions in 1- or 2-channel configurations.

PLUG & PLAY

Each Dante AVIO analog adapter is a complete, high performance Dante device, delivering all the automation and ease of use that have made Dante the most popular audio networking solution worldwide. Dante AVIO analog adapters are automatically discovered and ready to use when connected, and no separate power supplies are required – just use a common PoE (Power over Ethernet) switch and Dante AVIO analog adapters are ready to go.



USE CASES

ANALOG INPUT


- ▶ Connect legacy mixers and consoles to a Dante network
- ▶ Patch favorite DSPs, analog compressors and equalizers into a Dante system using a combination of Input and Output adapters
- ▶ Connect stage DI boxes and keyboard instruments directly to a Dante network
- ▶ Connect your wireless mic receiver to a Dante network

ANALOG OUTPUT

- ▶ Connect analog powered speakers to your Dante audio network.
- ▶ Send audio to analog power amplifiers over a Dante audio network.
- ▶ Create easy drop-points for connecting cry rooms and overflow areas to a Dante network.
- ▶ Connect non-networked hearing aid loop amplifiers to your Dante audio network.

FEATURES

- ▶ Plug & play operation
- ▶ Built for the road
- ▶ Sample rates up to 96 kHz
- ▶ 16, 24 and 32-bit audio support
- ▶ Excellent dynamic range, SNR and THD performance
- ▶ Configurable gain / attenuation
- ▶ Dante Audio over IP and AES67 RTP transport formats
- ▶ Power over Ethernet (PoE) support
- ▶ Dante Domain Manager ready



BUILT FOR THE ROAD

We've made Dante AVIO analog adapters road-ready and tour-tough. Sonically welded ABS enclosures and quality hardware are used throughout, while cable assemblies are stress-tested to ensure reliable operation under grueling conditions. Toss them in your toolbox, show after show.

ALL DANTE

Dante AVIO adapters are all fully functional Dante interfaces, with all the features you'd expect from Dante audio networking. Each one delivers bit-perfect audio reproduction, super-low latency and sample-accurate synchronization across the entire network. All Dante devices automatically discover one another, and the entire system is managed by our easy-to-use Dante Controller software on any connected PC or Mac. Most importantly, every Dante device can connect to every other Dante device – no questions asked.

All Dante AVIO adapters are fully compatible with Dante Domain Manager (DDM) for IT-level security and management, while AES67 is supported for connection to non-Dante networks.

COST-EFFECTIVE

We've worked hard to make the Dante AVIO family of products a cost-effective addition to any system or piece of gear, so that everyone can enjoy the benefits of Dante. Audio networking has never been easier to or more affordable, no matter how you choose to use it.

DANTE AVIO ANALOG INPUT & OUTPUT

Dante AVIO Analog Adapters allow you to use the audio gear you already own with your Dante network. Don't abandon trusted compressors, equalizers or analog power amplifiers - adapt them to the world of audio networking with Dante AVIO.

Dante AVIO Analog Adapters are available as balanced line-level single or dual-channel input or output adapters, with high-quality XLR connectors. Use the Analog Dante AVIO Adapters to add Dante networking to analog amplifiers, powered loudspeakers, signal processors, music players or any other analog audio device, for hum-free digital signal distribution throughout your audio network. ◀

WORLD WIDE OFFICES

Audinate Pty Ltd
Level 7 64 Kippax Street
Surry Hills NSW 2010
Australia
Tel: +61 2 8090 1000

Audinate Ltd
Suite 104
Werks Central
15-17 Middle St
Brighton, BN1 1AL
United Kingdom
Tel. +44 (0) 1273 921695

Audinate, Inc
1200 NW Naito Parkway
Suite 630
Portland, OR 97209
USA
Tel. +1.503.224.2998

Audinate Limited
Suite 1106-08, 11/
F Tai Yau Building
No 181 Johnston Road
Wanchai, Hong Kong
澳迪耐特有限公司
香港灣仔莊士敦道181號
大有大廈11樓1106-8室
Tel. +(852)-3588 0030
+(852)-3588 0031

SPECIFICATION	ANALOG INPUT 1 CHANNEL	ANALOG INPUT 2 CHANNEL	ANALOG OUTPUT 1 CHANNEL	ANALOG OUTPUT 2 CHANNEL
Max signal level (balanced)*	+24dBu / +4dBu / 0dBu		+18dBu / +4dBu / 0dBu	
	0dBV / -10dBV		0dBV / -10dBV	
Frequency Response	20Hz to 20kHz (-/+0.5dB)		20Hz to 20kHz (-/+0.5dB)	
Impedance	20k Ohm balanced 10k Ohm unbalanced		150 Ohm balanced 75 Ohm unbalanced	
Dynamic Range	> 100dB		> 100dB	
Signal to Noise Ratio	> 100dB		> 100dB	
Total Harmonic Distortion	< 0.01% at +4dBu		< 0.01% at +4dBu	
Connectors	RJ45 & 1 XLR-F	RJ45 & 2 XLR-F	RJ45 & 1 XLR-M	RJ45 & 2 XLR-M
Power	Class 1 802.3af PoE			
Sample Rates	44.1, 48, 96 kHz			
Bit Depth	24			
Dante Device Latency	1, 2, or 5ms (configurable using Dante Controller)			
Network Transport	Dante Audio over IP, AES67 RTP			
Part Number	ADP-DAI-AU-1X0	ADP-DAI-AU-2X0	ADP-DAO-AU-0X1	ADP-DAO-AU-0X2

info@audinate.com

www.audinate.com

Audinate, Dante and their logotypes are trademarks of Audinate Pty Ltd.

All other trademarks remain the property of their respective owners.

Audinate products are covered by numerous patents. See <https://www.audinate.com/patents> for details.
© 2020 Audinate Pty Ltd.
All rights reserved.

Dante AVIO Analog Marketing Datasheet

Audinate